

**Materials**

- 1) Perfume pendant kit **599**
- 2) Blank, minimum size:
5/8 x 1-3/4"
- 3) 27/64" drill bit **152**
- 4) Maxi-cure Extra-thick
CA **184**, epoxy **189**, or
polyurethane **192**
- 5) 5/8" barrel facing tool **331**
with rollerball pilot **335**
- 6) Ameroclassic mandrel
and bushing set **325**
- 7) The Spacer **352**
- 8) Sanding rolls, 4 pk. **1120**
- 9) HUT PPP combo **109**

Preparation

- 1) Cut blank approximately
1/4" longer than tube.
- 2) Drill blank with a 27/64"
drill bit.
- 3) Glue tube into blank with
CA, epoxy, or polyurethane.
- 4) When glue is cured,
square ends with barrel fac-
ing tool.

Turning

- 1) Turn on an Ameroclassic
mandrel with bushings **325**
at each end of the blank.
There will be some extra
space at the tailstock end.
Fill this with The Spacer or
extra bushings.
- 2) Sand and finish with HUT
PPP combo.

Assembly

- 1) Press end cap into tube.
- 2) Press threaded coupler
into blank, up to threads.
- 3) Insert perfume vial into
tube.
- 4) Affix ring cap on threaded
coupler and screw in.
- 5) Thread necklace cord into
the hole in the ring cap.

6-25-08