



0703 Money Clip Turning and Assembly Instructions

- Cut the piece to be turned slightly larger than the final thickness. Bring down to just greater than the final diameter on the band saw.
- Glue this piece to a scrap piece of wood attached to your faceplate, then turn to desired shape and correct diameter. Shape to your liking.
- Finish with HUT and remove with a parting tool or pop the glue loose. Sand the bottom smooth.
- When insert is finished, put on money clip by gently crimping the prongs around the insert.



Order online: www.hutproducts.com