









#### **Materials:**

- 1) Mini Stylus Kit 1476, 1777
- 2) Blank, minimum size: 1/2" or 5/8" x 1 1/4"
- 3) 9/32" drill bit 0171
- 4) Maxi-cure Extra-thick CA 0184, or Epoxy 0189
- 5) 5/8" barrel facing tool0331 with pilot 0333
- **6)** 7mm mandrel and bushing set **0298**
- 7) 7mm spacers
- 8) Sanding rolls, 4 pk. 1120
- 9) HUT PPP™ combo 0109 or HUT Crystal Coat™ 0104

### **Preparation:**

- 1) Cut blank to approximately 1/4" longer than the tube.
- **2)** Drill blank using a 9/32" drill bit.
- 3) Glue tube into blank.
- **4)** When glue is cured, square ends using a barrel facing tool.

#### **Turning:**

- 1) Turn on a 7mm mandrel with bushings 0298 at each end of the blank. There will be some extra space at the end of the mandrel. Fill this space with extra bushings. The blank may be turned as fancy as you like.
- **2)** Sand and finish with HUT PPP™ combo or HUT Crystal Coat™ **0104**.

## Assembly:

- 1) Gently place a bushing over the soft stylus tip and press into one end of turned barrel.
- **2)** Press finial into other end of barrel.
- 3) Insert split ring on lanyard into eye socket on finial.

7-12

4502 State Rd. J, Fulton, MO 65251 • 1-800-547-5461 • Fax 1-800-684-9371 • Email HUTpfw@aol.com • www.hutproducts.com

# Also Available!

Sierra Stylus Pen #1472



Turns on a 7mm mandrel with bushing set **0303**. Blanks are drilled with a 27/64 drill bit **0152**.

7mm Traditional Stylus Pen #1474



Turns on a 7mm mandrel with bushing set **0298.** Blanks are drilled with a 9/32 drill bit **0171.**