



4502 State Road J, Fulton, MO 65251

FAX: 1-800-684-9371

Order: 1-800-547-5461

Chrome Bottle Stopper

Stock #1652

Using a 6mm drill bit, drill a hole in a piece of wood a bit longer than the length of the screw on the bottle stopper kit. Screw the threaded end of the bottle stopper mandrel (Stock #0310) into this hole until the wood shoulders against the round stop collar. Mount the shaft of the mandrel onto your lathe using a chuck, drill chuck or split #1 morse taper. Support the other end of the wood on the tail stock center. Turn the wood to the desired shape.

Unscrew the mandrel from the wood and then screw the wood onto the bottle stopper screw. You may want to use glue to fix the wood on the stopper permanently.