





Fig. 2



Materials:

- 1) 24K gold letter opener kit 512
- **2)** Blank, minimum size: 5/8 x 5/8 x 2.5"
- 3) 9/32" drill bit 171
- 4) Maxi-cure Extra-thick CA 184 or epoxy 189
- 5) 5/8" barrel facing tool 331 with pilot 333
- 6) 7mm mandrel and 3-bushing set 370
- **7)** The Spacer **351**
- **8)** Sanding rolls, 4 pk. **1120**
- 9) HUT PPP combo 109

Blank Preparation:

- 1) Cut a 5/8 x 5/8" blank approximately 2.5" long.
- 2) Drill blanks with a 9/32" drill bit.
- 3) Glue tubes into blanks.
- **4)** When glue is cured, square ends with barrel facing tool using a 7mm pilot.
- 5) Turn on a 7mm mandrel with bushing set 370, arranging bushings as shown (Fig. 1). Only 2 bushings are needed. Fill excess mandrel space with extra bushings or The Spacer 351.

Turning:

- 1) Turn blank down to the bushings.
- 2) Handle design is optional. Be as creative as you want!
- 3) Sand and finish with HUT PPP combo. Finish with a two-step process; first apply PPP Satin Gloss, then PPP High gloss for a perfect pen polish!

Assembly:

- 1) Slide one or both rings (your choice) over small tube end of hilt. Press hilt into large end of handle, flush with wood, and glue asnecessary.
- **2)** Press finial into small end of handle.
- 3) Slide blade through round hole in hilt—threaded end first. Screw threaded tang tightly into threads of finial. (Do not glue to allow for replacement of blade.)

9/23/98